



SALUS
CONTROLS

09.12.2020

RT310
RT310RF

HEAT / COOL modes

SOFT 2.1




HEAT mode active
– flame icon is stable



calling for HEATING
– flame icon is flashing

To change HEAT/COOL mode, hold snowflake button for 5 seconds



COOL mode active
– snowflake icon is stable




calling for COOLING
– snowflake icon is flashing




*in COOL mode thermostat starts cooling with 3 minutes delay

DIP SWITCH position settings (on the back of the thermostat)



1	2	COOL mode	HEAT mode	
ON	ON	Span +/- 0.25	Span +/- 0.25	
OFF	ON	Span +/- 1.5	Span +/- 0.5	
ON	OFF	Span +/- 1.0	TPI 9 CPH	
OFF	OFF	Span +/- 0.5	TPI 6 CPH	DEFAULT SETTINGS

To go back to HEAT mode again,
hold snowflake button for 5 seconds



Pay attention to the icons on the display !!!!!



CLICK



FROST PROTECTION mode



HEAT mode



COOL mode

**More informations about SALUS Controls products you
can find here:**

www.salus-controls.pl

and

www.salus-smarthome.pl